





 <p>MS 150</p> <p><b>MS 150 M 12</b></p>	<p>Düse 3906</p> 
	<p>Düse 3911</p> 
	<p>Düse 3905</p> 
	<p>Düse 3901</p> 
	<p>Düse 3680</p> 
	<p>Düse 3681</p> 



MS 150

**MS 150 M 12**

Adapter 3961



Düse 1143



Düse 3504



Düse 3205



Düse 3206



Düse 3207



Düsenkappe 3135



Düse 3208



Düse 3240





MS 150

**MS 150 M 12**

Adapter 3961



Grunddüse 3508



Düseneinsatz 3502



Düseneinsatz 3531



Kehlnahtdüse 3503



Injektionsnadel 3509



2 Lochdüse 3670



3 Lochdüse 3671



5 Lochdüse 3679



Adapter 3961



Adapter 3688



Flachdüse 3672



Verl.düse 3676



Nadeldüse 3677





MS 150

**MS 150 M 12**

Adapter 3910



3757  
Kugel  
○

3789  
Feder  
≡

Spitzdüsenkopf 3902



Düsenkopf Nr.1 3903



Düsenkopf Nr.3 3904



Düsenkopf Nr.2 3909



Schlitzdüsenkopf 3716



Schlitzdüsenkopf 3717

